

XEROX®

Technology | Document Management | Consulting Services

**Imaging Supplies Co. Inc.**
Sanford, NC 27330
(919) 776 1152

fax | print | copy | scan

Valuable functions, value-priced.

Fax machine. Printer. Copier. Scanner.

At the heart of the Xerox FaxCentre® F116 multifunction device is a robust and powerful fax machine. Yet – with its quick network-capable printing, convenience copying, color scanning, email and internet access – it opens the door to a multitude of critical desktop resources for the single user or small office. All in a compact and truly affordable package.





Specifications

FAX

Compatibility: ITU - T.37
 Modem Speed: 33.6 Kbps
 Compression: MMR/MR/MH/JBIG
 Super G3
 Transmission: 3 seconds per page
 Dual Lines: Yes on F116L,
 No on F116

Resolutions

Mono:
 Standard (100 x 200 dpi)
 Fine (200 x 200 dpi)
 Super Fine (400 x 200 dpi)
 Photo Mode (200 x 200 dpi)
Color:
 Standard (100 x 100 dpi)
 Fine (200 x 200 dpi)
 Super Fine (300 x 300 dpi)
 Halftones: 256 levels
 Fax Memory: 8 MB (500 pages
 of ITU-T chart 1 with standard
 resolution)
 Memory Receive: Yes (Receive faxes
 while printing other jobs from direct
 connect or network)
 Set Prefix Option: Yes
 One Touch Dials: 26
 Speed Dials: 500 entries with
 Alphanumeric search
 Battery Back up: None req'd. Constant,
 battery = free memory for jobs
 Auto reduction receive: Yes,
 Documents automatically reduced
 to fit the recording (loaded) paper size
 Device Access/Security (Secure fax):
 32 mailboxes (1 public, 31 private
 password-protected)
 Up to 98 user codes or Dept. codes
 Can Also:
 Lock printing of received faxes
 Lock Keyboard
 Lock number keypad
 Lock internet settings

CONVENIENCE PRINTING

Technology: Laser Monochrome
 Speed: 16 pages per minute (ppm)
 Resolution: 600 x 600 dpi
 Print Memory: 32 MB
 Duplex: No
 Connectivity - Standard: Direct connect
 - via USB
 Connectivity - Optional: Internal Network
 Printing Kit

CONVENIENCE COPYING

Speed: 16 ppm
 Resolution: 300 x 300 dpi
 Reduce/Enlarge: 25-400% in 1%
 increments
 Multiple Copies: Up to 99 copies
 Productivity: Scan Once/Print Many

CONFIGURATIONS	FaxCentre® F116	FaxCentre® F116/L
Copy/Print		
Speed		16 ppm
First copy out time		17 seconds
Resolution	300 x 300 dpi copy / 600 x 600 dpi print	
Processor	92 Mhz	
Connectivity	Direct Connect via USB; optional internal NIC	
Scan		
Resolution	300 x 300 dpi optical; 600 x 600 dpi interpolated	
Scan to e-mail	yes	
Fax		
Speed	33.6 Kbps	
Resolution	up to 400 x 200 dpi monochrome or up to 300 x 300 dpi color	
Transmission	3 seconds per page	
Dual Lines	No	Yes
Paper Handling		
Paper input capability	250 sheets	
Paper output	100 sheets	
Productivity		
Special features	Color scan to email	
Optional Accessories	Optional 500-sheet paper tray	
Duty Cycle	2500 pages / month	

SCANNING (Color and Monochrome)

Avq. Scan Speeds:
 100 x 200 dpi: 1.8 seconds per page
 300 x 300 dpi: 5.4 seconds per page
 Color: 16 seconds per page
 Maximum Resolution: Optical 300 x 300
 600 x 600 Interpolated
 Scan Driver: TWAIN Standard Scanning
 Software Document Management and
 OCR: ScanSoft® PaperPort® and
 OmniPage® Software

EMAIL

Compatibility: ITU T37
 Mail Protocol - sending: SMTP
 SMTP Authentication:
 Yes (only RFC 1734)
 Mono email format: TIFF-F, PDF
 Color email Format: JPEG

LAN ACCESS

Ethernet: 10 BaseT/100BaseT
 Plug & Play configuration: Yes
 (DHCP and BOOTP)
 Internet Protocol: TCP/IP
 DNS Queries: Yes (2 DNS servers access)
 NETBIOS compatibility
 (for name management): Yes
 Respond to PING request: Yes

MEDIA HANDLING

Input Paper Capacity
Main Tray: 250 sheets
 Minimum Size: 5 x 8 in / 120 x 208 mm
 Maximum Size: 8.5 x 39.4 in /
 216 x 1000 mm
 Weights: 60 x 90 gsm / 16-24 lb bond
Bypass Tray: 1 sheet
 Envelope feeding: Yes
 (using bypass tray)
Additional Tray 2 (optional): 500 sheets
Automatic Document Feeder: 35 sheets
 Output Capacity: 100 sheets

PHYSICAL CHARACTERISTICS

Footprint: 15 3/8 x 18 1/8 x 15 3/8 in. /
 389 x 460 x 390 mm
 Weight: 24.3 lb / 11 kg (machine only)

ELECTRICAL

Power Switch: Yes
 Power Requirements:
 220 to 240 VAC, 50/60 Hz
 (Europe)
 100 to 127 VAC, 50/60 Hz
 (N. America & Latin America)
 Maximum Power Consumption:
 850 watts
 Power Saver Mode: 15 watts or less
 Energy Saver: ENERGY STAR®
 Compliant

OPERATING ENVIRONMENT

Temperature: 50°- 89.6°F, 10°- 32°C
 Humidity: 20 - 80%

GENERAL SPECIFICATIONS

Total Device Memory: 32 MB SDRAM;
 64 MB Flash Memory
 Device Management:
 Companion Pro Software

SUPPLIES

Approximate Yields Toner-
 Starter Kit: 2,000 prints*;
 Replacement Kit: 6,000 prints*
Drum Cartridge-Starter: 4,000 prints*;
 Replacement Photoreceptor/Drum
 Cartridge: 20,000 prints*

* Capacities are approximate, based on 5% cover-
 age on an A-size page and dependent on customer
 job mode run length

AGENCY APPROVALS

UL Safety

**Reduce operating costs and
 save space by consolidating
 functions into one powerful,
 office machine.**

**Robust and affordable
 All the essentials at one low price.**

- 33.6 Kbps faxing provides quick transmission of multi-page documents in as little as 3 seconds a page
- Secure fax with 31 password-protected mailboxes to receive documents confidentially
- Dual-line fax capabilities on F116L means that two lines are always available for transmission and/or reception
- Outstanding laser technology and PCL6 printing from PC or network for highest quality documents
- Scanning in full color (or black-and-white) to email via the internet

**Productivity-boosting
 High-tech features do it all.**

- Faxes can be scanned and sent electronically to recipients with verification of sender
- Thanks to protected memory, saved faxes and device settings are never lost if power is interrupted
- When receiving data, the F116 automatically reduces a document to fit the loaded paper size in tray
- "Intelligent" consumables let users know when toner is low

**Compact and convenient
 Efficiency simplifies your workday.**

- Well suited for a countertop or desktop use in offices where space is at a premium
- Extra tray option meets the needs of high-volume users
- Easy-to-use keypad makes it a breeze to perform any function
- Text messaging to fax for communication convenience

